

Care and Handling of DVDs

- 1) Handle the DVD carefully, making contact only with the outer edge. Do not touch the disc surface.
- 2) To remove the disc from its case, press the “push” button on the center of the case and press downward. Then, using your other hand, gently remove the disc by its outer edge. Never remove the disc by prying at its outer edge.
- 3) Store the disc inside its protective case when not in use.
- 4) Do not stack discs inside a case.
- 5) Do not place a disc on any surface, as the clear coating of the disc may get scratched.
- 6) Keep discs away from extreme heat, such as direct sunlight, and keep them away from sources of dust. It is best to store discs at room temperature, though they are not as vulnerable to damage from extreme hot or cold temperatures as magnetic media.
- 7) Don't place heavy objects on the disc.
- 8) Insert a single-sided DVD with the artwork or graphic side up inside your player.
- 9) Make sure the disc is properly seated inside the player before closing the drawer.
- 10) If a DVD seems to be dirty, you may try cleaning it with a damp, lint-free, non-abrasive cloth. Do not use any harsh cleaning agents. Wipe the disc using straight motions from the inside hole to the outer edge. Do not use circular motions when cleaning.